

Skötselråd – Teak/Tygband/Konstrottingband

Produktfördelar

Teak är ett mycket tåligt träslag med goda egenskaper som passar utmärkt som utomhusmöbler. Varje möbel i teak har sin egna karaktär och struktur. Sprickor, framförallt i skarvar samt i träets fiberriktning, kan komma att uppstå. Detta är helt normalt och ett tecken på materialets levande egenskaper.

Rengöring & underhåll

Rengör regelbundet teakmöblerna med en blandning av ljummet vatten och mild tvättmedel. Använd en mjuk borste eller svamp för att skrubba ytan och avlägsna smuts och fläckar. Skölj noga med rent vatten för att avlägsna alla tvålrester. Undvik att använda högtryckstvätt eller aggressiva rengöringsmedel, eftersom detta kan skada träytan.

Mögel och fläckar

För att ta bort mögel- eller mögelfläckar, använd en lösning av blekmedel och vatten. Applicera försiktigt på de drabbade områdena och låt verka i några minuter innan du sköljer noggrant.

För envisa fläckar kan du använda ett slipande rengöringsmedel eller fint sandpapper för att försiktigt slipa bort fläcken. Se till att du arbetar i träets ådringens riktning och undviker överdriven slipning.

Återställa färg och glans

Om teakmöblerna har blekts eller förlorat sin naturliga färg på grund av exponering för solen, kan du återställa färgen genom att applicera teakolja. Applicera oljan jämnt över ytan med en mjuk trasa och låt den absorberas ordentligt. Torka sedan bort överflödiga olja med en ren trasa. Om du föredrar den naturliga silvergrå patinan som teak utvecklar över tiden, kan du enkelt låta möblerna åldras naturligt utan någon ytterligare behandling.

Sprickor i teak

Det är naturligt att teakträ utomhus kan utveckla sprickor över tiden. Teakträ är ett tropiskt träslag som är känt för sin naturliga rörelse och anpassningsförmåga till väder och klimat. När teak träffas av sol, regn, fukt och temperaturväxlingar, kan träet expandera och dra ihop sig, vilket kan leda till sprickbildning. Dessa sprickor är en del av träets naturliga åldringsprocess och påverkar inte nödvändigtvis dess hållbarhet eller funktionalitet. Även om sprickor kan vara oestetiska, kan de ofta förhindras eller minimeras genom att ta några förebyggande åtgärder. Till exempel, regelbunden rengöring och oljning av teakmöbler kan bidra till att bevara träets fuktighet och flexibilitet, vilket minskar risken för sprickbildning.

Om din teakmöbel har konstrottingband

Torka av möblerna regelbundet med en mjuk svamp eller trasa för att avlägsna damm, smuts och andra föroreningar. Detta hjälper till att förhindra att smutsen tränger in i rottingens fibrer och gör den svår att rengöra. Var försiktig när du hanterar möblerna för att undvika repor och skador på rottingen. Undvik att använda skarpa eller vassa föremål som kan skada ytan och undvik att dra tunga föremål över möblerna.

Om din teakmöbel har konstrottingband

För att hålla dina tygband i bra skick och förlänga livslängden på möblerna, rekommenderas att rengöra dem regelbundet. En mild tvål och vattenlösning är ofta tillräcklig för att ta bort smuts, fläckar och damm. Använd en mjuk borste eller trasa för att undvika att repa ytan. Undvik starka kemikalier eller blekmedel, då de kan skada materialet. Låt möblerna torka ordentligt efter rengöring.

Vinterförvaring

Teak är naturligt motståndskraftigt mot väderförhållanden, men att använda ett möbelskydd under vintermånaderna kan hjälpa till att skydda möblerna från extrema förhållanden och förlänga deras livslängd.

Om möblerna inte används under långa perioder, förvara dem på en torr plats för att förhindra fuktinträngning och mögelbildning.

Care instructions – Teak/Artificial rattan ribbons/Fabric ribbons

Product benefits

Teak is a highly durable wood with excellent properties, making it ideal for outdoor furniture. Each piece of teak furniture has its own unique character and texture. Cracks, especially at joints and along the wood grain, may occur. This is completely normal and a sign of the material's natural and living qualities.

Cleaning & maintenance

Regularly clean your teak furniture with a mixture of water and mild detergent. Use a soft brush or sponge to scrub the surface and remove dirt and stains. Rinse thoroughly with clean water to remove all soap residue. Avoid using pressure washers or harsh cleaning agents, as these can damage the wood's surface.

Mold and stains

To remove mold or mildew stains, use a solution of bleach and water. Gently apply it to the affected areas and let it sit for a few minutes before rinsing thoroughly.

For stubborn stains, you can use an abrasive cleaner or fine sandpaper to carefully sand away the stain. Be sure to work in the direction of the wood grain and avoid excessive sanding.

Restoring color and shine

If your teak furniture has faded or lost its natural color due to sun exposure, you can restore it by applying teak oil. Apply the oil to the surface with a soft cloth and allow it to absorb thoroughly. Then, wipe away any excess oil with a clean cloth. If you prefer the natural silver-gray patina that teak develops over time, you can simply allow the furniture to age naturally without additional treatment. Be sure to clean the furniture regularly to remove dirt and maintain its appearance and durability.

Cracks in teak

It is natural for teak wood used outdoors to develop cracks over time. Teak is a tropical hardwood known for its natural movement and adaptability to weather and climate. When teak is exposed to sun, rain, moisture, and temperature fluctuations, the wood can expand and contract, which may lead to cracking. These cracks are part of the wood's natural aging process and do not necessarily affect its durability or functionality.

Although cracks may be unsightly, they can often be prevented or minimized by taking some preventative measures. For example, regular cleaning and oiling of teak furniture can help preserve the wood's moisture and flexibility, reducing the risk of cracking.

If your teak furniture has artificial rattan ribbons

Wipe the furniture regularly with a soft sponge or cloth to remove dust, dirt, and other impurities. This helps prevent dirt from penetrating the rattan fibers, making it difficult to clean. Be cautious when handling the furniture to avoid scratches and damage to the rattan. Avoid using sharp or pointed objects that could damage the surface, and refrain from dragging heavy items across the furniture.

If your teak furniture has fabric ribbons

To keep your fabric ribbons in good condition and extend the lifespan of the furniture, it is recommended to clean them regularly. A mild soap and water solution is usually sufficient to remove dirt, stains, and dust. Use a soft brush or cloth to avoid scratching the surface. Avoid strong chemicals or bleach, as they can damage the material. Allow the furniture to dry thoroughly after cleaning.

Winter storage

Teak is naturally resistant to weather conditions, but using a furniture cover during the winter months can help protect the furniture from extreme conditions and extend its lifespan. If the furniture will not be used for extended periods, store it in a dry place to prevent moisture infiltration and mold growth.