



# Einhell

# EXPERT



Cordless Chain Saw

**GE-LC 18/25-1 Li Kit**  
**(1x3,0Ah)**

**Item No.: 4501760**

Ident No.: 21042

Bar Code: 4006825608335

The Einhell cordless GE-LC 18/25-1 Li Chainsaw Kit combines the outstanding performance of an Einhell product with a high-quality OREGON guide bar and chain. Kickback protection with an instant-reaction mechanical chain brake and a stop claw keep you safe while you are working with the chainsaw. The rugged metal stop claw keeps the saw stable while you are working, and the ergonomic handle gives you a comfortable grip on the chainsaw. No tools are needed to adjust the chain tension or replace the chain. A big filler opening of the automatic chain lubrication system makes it easy to top it up if necessary. The set includes a fast charger and battery which can be used for all Power X-Change family products.

## Features & Benefits

- Battery system - Power X-Change
- Battery charge level indicator with 3 LEDs
- Battery can be used for other Power X-Change products
- System high-speed charger included
- High-quality chain and bar from OREGON
- Toolless chain tensioning and changing
- Ergonomic handle
- Sturdy stop claws made of metal
- Kickback protection with mechanical instant chain brake
- Big filler opening
- Automatic chain lubrication
- Chain catch bolt



## Technical Data

- Sword length 250 mm
- Max. cutting length 23 cm
- Chain cutting speed 4.5 m/s
- Oil tank capacity 200 mL



## Logistic Data

- Product weight (kg) 2.97 kg
- Gross weight (kg) 4.97 kg
- Dimensions single packaging 225 x 480 x 245 mm
- Pieces per export carton 4 Pieces
- Gross weight export carton 16.5 kg
- Dimensions Export Carton 500 x 380 x 515 mm
- Container quantity (20"/40"/40"HC) 1088 | 2208 | 2760



## Available as special accessories



Spare Bar 25cm 1,1  
Chain Saw Accessory  
Item No.: 4501753  
Bar Code: 4006825607017  
Einhell Accessory



Spare Chain 25 cm 1,1 40T 3/8  
Chain Saw Accessory  
Item No.: 4501754  
Bar Code: 4006825607024  
Einhell Accessory



18V 2,0Ah Power X-Change  
Battery  
Item No.: 4511395  
Bar Code: 4006825610369  
Einhell Accessory



18V 4,0Ah Power X-Change 1  
Battery  
Item No.: 4511396  
Bar Code: 4006825610376  
Einhell Accessory



18V 4,0Ah PXC Starter Kit 1  
PXC-Starter-Kit  
Item No.: 4512042  
Bar Code: 4006825613704  
Einhell Accessory



18V 5,2Ah Power X-Change Plus  
Battery  
Item No.: 4511437  
Bar Code: 4006825616606  
Einhell Accessory



Power X-Twincharger 3A  
Charger  
Item No.: 4512069  
Bar Code: 4006825629729  
Einhell Accessory



18V 2,0Ah PXC Starter Kit  
PXC-Starter-Kit  
Item No.: 4512040  
Bar Code: 4006825613681  
Einhell Accessory




Power X-Boostcharger 6A  
Charger  
Item No.: 4512064  
Bar Code: 4006825629019  
Einhell Accessory



18V 3,0 Ah Power-X-Change 2  
Battery  
Item No.: 4511341  
Bar Code: 4006825590593  
Einhell Accessory

## Battery-Running-Times

One Battery for All	 sawing <sup>1</sup> (pieces)
1.5 Ah	50
2.0 Ah	70
2.5 Ah	85
3.0 Ah	100
4.0 Ah	130
5.2 Ah	180
6.0 Ah	200
8.0 Ah	260

For best performance select a battery with at least 2.5 Ah

Test setup:

1) wood - scantling 70x70 mm