

REPSTEGE

Modell 62-45-1, 62-75-1 och 62-105-1

VARNING

ATT INTE LÄSA OCH FÖLJA DESSA INSTRUKTIONER KAN RESULTERA I ALLVARLIGA SKADOR ELLER DÖDSFALL.

Du måste känna till hur denna produkt fungerar innan användandet. Bärbara nödstegar är avsedda att användas för att utrymma bostadshus som supplement till de utrymningsanordningar som krävs av byggnadskoder och andra lokala regler.

Det är starkt rekommenderat att du övar fastsättningen av nödstegen vid fara enligt beskrivningen i steg 1, 2 och 3 i dessa instruktioner. Vid övning DRA INTE I UTLÖSNINGSTAMPEN SOM FÅR STEGEN ATT ÖPPNAS

Din nödstege har monterats noggrant för att garantera att den fungerar vid nödfall.

Låt inte stegänden falla ner i öppen eld. Släng stegen efter användandet.

Vid normalt användande är det möjligt att stegen kan skrapa, buckla eller skada fasaden på ett hus. Det är inte rekommenderat att använda stegen i stormfönster eller andra fönster som inte kan öppnas fullt och ge en öppning som uppfyller minimidimensionerna.

Var också noga med att inte använda nödstegen i ett fönster placerat omedelbart ovanför ett annat fönster då skador kan uppkomma på det nedre fönstrets glas och ram.

Vi rekommenderar att nödstegen bytes ut vart 15:e år för att garantera optimal hållbarhet och funktion.

Denna nödstege är menad som ett komplement till (ej ersättning för) de viktigare brandskyddsprinciperna såsom brandövningar, nödutgångsplaner, röklarm, brandsläckare etc.

Får ej förvaras i direkt solljus eller vid höga temperaturer. Total belastning på nödstegen får ej överstiga 450kg. Nödstegen är ingen leksak och skall inte användas av barn utan en förälders uppsikt.

ANDVÄNDNINGSGREGLER

I utrullat tillstånd från ett fönster, måste nedersta steget vara tillräckligt nära marken för att möjliggöra en säker nedstigning. Använd inte nödstegen vid högre höjd än 4,8, 7,5 resp. 10,0 m då skador kan inträffa.

Fönstret som stegen är fastgjord vid måste kunna motstå belastningen av de personer som använder stegen. Fönstret måste också vara lätt att nå och utan galler eller andra hinder. Fönstret måste kunna öppnas helt för att möjliggöra utrymning. Kontrollera att utsidan är fri från hinder som elkablar, telefontrådar eller staket.

Minimibredden på utrymningsfönstret där nödstegen används är 41cm. Maxtjockleken på fönsterkarmen är 30cm.

Denna utrymningsstege skall endast användas som sista utpost. Instruera familjemedlemmarna att i första hand använda huvudutgångar om möjligt innan nödstegen tas i bruk.

INSTRUKTIONER FÖR ANVÄNDANDET AV NÖDSTEGEN

STEG 1. Stäng dörren till rummet innan utrymningsfönstret öppnas för att undvika att intensifiera en brand

2. Öppna fästkrokarna och dra ut mittenstaget.
3. Placera krokarna på insidan av fönsterkarmen med stegen hängande på utsidan av husväggen. Gör fast änden av kroken på väggens insida. Den andra änden av kroken måste vara på fönstrets utsida.
4. Dra i utlösningstampen så att nödstegen = rullas ut (SKA ENDAST GÖRAS VID EN RIKTIG NÖDSITUATION)
5. Kliv försiktigt ut från fönstret och på stegen, håll i fästkrokarna för stadga.
6. Under nedstigandet, håll kroppen nära stegen för ökad stabilitet. Bär barn på stegen endast i yttersta nödfall. Undvik att bära husdjur eller andra föremål under nedklättringen.
7. Om hela familjen utrymmer så bör en vuxen gå först för att stabilisera stegen innan barn och äldre klättrar ner.
8. Var försiktig och undvik att krossa glaset i närliggande fönster under nerklättringen.

FÖRVARING

Förvara nödstegen nära det fönster som ska användas. En bra plats är ett skåp eller under en säng nära fönstret. Förvaras ej i direkt solljus eller vid höga temperaturer.

PLANERA FÖR EN NÖDUTRYMNING

Gör upp en utrymningsplan och träna utförandet av planen. En utrymningsplan skall ha minimum två olika sätt att utrymma varje rum (dörr och fönster), en samlingsplats utanför bostaden och ring 112 efter utrymningen.



ROPE LADDER

Model 62-45-1, 62-75-1 and 62-105-1

WARNING

FAILURE TO READ AND FOLLOW THESE INSTRUCTIONS COULD RESULT IN SERIOUS INJURY OR DEATH

You must be familiar with the operation of this product prior to use. Portable rope ladders are intended for use as a means of escape from residential buildings and to supplement the primary means of egress required by codes and other local regulations.

It is strongly recommended that you practice mounting the ladder for deployment as described in steps 1, 2 and 3 under instructions for use of this ladder. During practices, **DO NOT PULL THE RELEASE STRAP TO DEPLOY THE LADDER.**

Your ladder has been carefully assembled to ensure proper deployment when needed.

Do not deploy ladder into flames. Dispose of ladder after use.

In normal use, it is possible that this ladder may scratch, dent or blemish the exterior surface of a home. Not recommended for use with storm windows or other windows that do not open fully to the recommended minimum space. Further care should be taken to ensure that the ladder is not used from any window that is above another window. Failure to take this precaution may lead to damaged window glass, screens or wood trim.

We recommend replacing the ladder every 15 years to ensure optimum strength and performance.

This ladder is intended to supplement (not replace) the more important fire protection principles of fire drills, emergency exit plans, smoke alarms, fire extinguishers etc.

Do not store in direct sunlight or at elevated temperatures. Do not exceed 1000 pounds cumulative (454kg) load on this ladder. This ladder is not a toy and should not be used by children unless supervised by an adult.

CONDITIONS FOR USE OF THIS LADDER

When extended from the window, the bottom step of the ladder must be close enough to the ground to allow for a safe escape.

The length of 62-45-1 ladder is approximately 15 feet (4.78m) (2 Stories). Do not use this ladder from heights greater than 16 feet (4.9m) as injury could result.

The length of 62-75-1 ladder is approximately 24 feet (7.5m) (3 stories). Do not use this ladder from heights greater than 26 feet (7.9m) as injury could result.



The length of 62-105-1 ladder is approximately 32 feet (10.0m) (3 stones). Do not use this ladder from heights greater than 34 feet (10.5m) as injury could result.

The window to which the ladder is attached must be able to support the load of persons using the ladder for escape. The escape window must not be obstructed or covered with grilles or bars. The window must open fully for escape. Look for outside obstacles such as electrical wire, telephone wires or fences.

The minimum width of escape window for use of the ladder is 16 inches (0.41 meters). The maximum thickness of the escape window opening is 11 inches (0.28meters).

This escape ladder is to be used only as a last emergency device. Instruct family members to use the main escape routes if possible before using the ladder.

INSTRUCTIONS FOR USE OF THIS LADDER

1. Close the doors to the room before opening the escape window to avoid intensifying a fire.
2. Open attachment hooks and extend center Support.
3. Place hooks over window sill with ladder hanging on the outside of the structure. Attach the end of the hooks to the inside wall. The other side of the hooks must be outside the window.
4. Pull release strap to deploy ladder.(TO BE DONE ONLY IN AN ACTUAL EMERGENCY).
5. Carefully exit window onto ladder, holding attachment hooks to provide stability.
6. When descending the ladder keep your body close to the ladder to maximize stability. Carry children on the ladder only when it is absolutely necessary. Avoid carrying pets or other objects on the ladder.
7. In family escape, the parent should exit first to stabilize the ladder during the descent of children or elderly adults.
8. Be careful to avoid breaking glass in adjacent windows when descending the ladder.

STORAGE

Store the ladder near the window. where it will be used. A closet or under the bed near the window where it can be easily reached is a useful storage place. Do not store in direct sunlight or elevated temperatures.

PLANNING FOR EMERGENCY ESCAPE

Prepare an escape plan and practice the plan. The plan should include as a minimum two means of escape from each room (door and window), a meeting place to gather outside the residence, and call 112 services after the exit.