



Einhell

CLASSIC



Cordless Speaker

TC-SR 18 Li BT - Solo

Item No.: 4514150

Ident No.: 11019

Bar Code: 4006825644531

The Einhell TC-SR 18 Li BT - Solo cordless speaker makes it easy to connect up to all Bluetooth-enabled devices such as smart phones or tablets. In addition, the speaker has an AUX connection for connecting MP3 playery or smart phones, plus an USB connection for charging a smart phone, tablet or MP3 player. An intuitive control panel makes it easy to use. As a member of the Power-X-Change series, all the high-quality lithium-ion rechargeable batteries from the system series can be used in combination with the cordless speaker. This product comes without a battery and charger. These are available separately, for example as a practical starter set.

Features & Benefits



- A member of the Power X-Change family
- Easy connection with the device thanks to Bluetooth
- AUX connection for connecting an MP3 player, mobile phone, etc.
- USB connection for charging a mobile phone, tablet or MP3 player
- Intuitive control panel makes it easy to use
- Supplied without battery and charger (available separately)

Technical Data

- Voltage output USB	5 V
- Current output USB	2 A
- Speaker output power	2 x 3 W
- Max. loudness	85 dB (A)
- Output frequency	120 Hz - 20 kHz
- Bluetooth Version	5.0

Logistic Data

- Product weight (kg)	0.29
- Gross weight (kg)	0.45
- Dimensions single packaging	143 x 120 x 122 mm
- Pieces per export carton	12 Pieces
- Gross weight of export carton	5.9 kg
- Dimensions export carton	377 x 300 x 270 mm
- Container quantities (20"/40"/40"HC)	10944 22176 24948



Available as special accessories



18V 4-6Ah Multi-Ah PXC Plus
Battery
Item No.: 4511502
Bar Code: 4006825644210
Einhell Accessory



18V 2,0Ah Power X-Change
Battery
Item No.: 4511395
Bar Code: 4006825610369
Einhell Accessory



18V 4,0Ah Power X-Change 1
Battery
Item No.: 4511396
Bar Code: 4006825610376
Einhell Accessory



18V 4,0Ah PXC Starter Kit 1
PXC-Starter-Kit
Item No.: 4512042
Bar Code: 4006825613704
Einhell Accessory



18V 5,2Ah Power X-Change Plus
Battery
Item No.: 4511437
Bar Code: 4006825616606
Einhell Accessory



Power X-Twincharger 3A
Charger
Item No.: 4512069
Bar Code: 4006825629729
Einhell Accessory



18V 2,0Ah PXC Starter Kit
PXC-Starter-Kit
Item No.: 4512040
Bar Code: 4006825613681
Einhell Accessory



18V 3,0Ah Power X-Change Plus
Battery
Item No.: 4511501
Bar Code: 4006825644197
Einhell Accessory



18V 3,0 Ah Power-X-Change 2
Battery
Item No.: 4511341
Bar Code: 4006825590593
Einhell Accessory

Battery-Running-Times

One Battery for All	 running time ¹ (h)
1.5 Ah	43
2.0 Ah	57
2.5 Ah	72
3.0 Ah	86
4.0 Ah	114
5.2 Ah	148
6.0 Ah	171
8.0 Ah	228

Test setup:

1) -