


Window Awning



1,2 x 0,7m

1,4 x 0,7m

2,0 x 0,7m

ENG

Window Awning

Read the user manual carefully to make sure that the product is assembled, used and maintained correctly, as described in the instructions in this user manual. Keep the user manual for future reference.

SAFETY INSTRUCTIONS


- Carefully follow the safety and assembly instructions and save the user's manual for future use.
- The awning is mounted on the wall of a home and extended using the rope. The awning canopy provides protection from the sun and privacy, and is not intended for use as rain cover. The awning is intended for private use.
- Do not use the awning if it is damaged in any way.
- Technical skills are required for installation of the awning. Do not install the awning yourself if you are uncertain as to how the awning can be installed in the place where you intend to install it, if you do not understand the user's manual or parts thereof, if you do not have the necessary tools or if you do not have the necessary skills. Contact a qualified installer for assistance.
- Keep children and pets at a safe distance when you install and adjust the awning.
- Make sure that your hands are clean when you install the awning otherwise the canopy and the frame can become dirty.
- Using the awning when there is frost can damage the awning.
- Retract the awning when there is rain or heavy wind.
- Climbing on the awning and hanging objects from the awning are prohibited.
- Do not place any kind of fire under the awning.



WARNING!








If these instructions are not followed, an accident may lead to serious personal injury or property damage.

DESCRIPTION



PACKAGE CONTENTS

- Make sure that all the parts were included in the package and that they are not damaged. Do not install the awning if any parts are missing or damaged. Contact your retailer.
- **NOTE! The bolts for wall mounting are not included. Consult with a professional to determine which bolts are suitable for your wall.**

Part	Picture	Number	Part	Picture	Number
A Awning		1 pce	E Screw	 ST4.8x40	10 pcs
B Cord holder		1 pce	F Anchor	 Ø8x45	10 pcs
C Wall mount		2 pcs	G Screw	 M6x14	6 pcs
D Washer	 Ø6	10 pcs			

ASSEMBLY

- The following tools are required for installation (not included):



Measuring tape




Philips screwdriver




Level



Drill



Wall brackets




Awning cassette

1

Determine the height and mark a line on the wall using a spirit level. The line marks the top edge of the wall brackets. It is essential that line is straight.


2

- Make sure that the awning's cord is positioned in the left side seen from the front of the awning cassette. It is important that the wall bracket is positioned on the wall so that the awning's cord can easily run through the hole in the wall bracket.
- Fasten the wall brackets on the wall with bolts that are suitable for your wall (not included).
- Mount the awning cassette on the wall brackets by hanging the awning cassette on the upper part of the respective wall bracket and then pressing the cassette towards the wall until an audible click is heard.



3

- The distance between the underside of the wall brackets and the upper attachment point of the arms should be 62.0 cm.
- Fasten the arms on the wall with screw D and washer E.
- Use anchor E for installation in solid concrete walls or brick.




4

The cord holder can be mounted on the inside or outside of the wall. If you want the cord holder on the outside of the wall, follow step 4A. If you want the cord on the inside of the wall, follow step 4B.


4A – OUTSIDE OF THE WALL

- The cord holder is mounted plumb on the wall directly below the cord hole in the wall mount so that the cord runs straight downwards.
- Mount the cord holder with screw G and washer F.
- Use anchor E for installation in solid concrete walls or brick.



5

The awning is extended by releasing the cord from the cord holder and then the awning is lowered to the desired position. The cord must always be taut and held against the wall in order for the locking mechanism in the cord holder to release. Continue to hold the cord taut until the desired position is reached. Then pull the cord towards you and ease up on the tension so that the cord holder locks the cord in the desired position.



The awning's valance can be easily removed sideways if you prefer the awning without it.

MAINTENANCE

- Regular maintenance is important for safety purposes and for extending the service life of the awning.
- Avoid stains on the awning. The awning should be clean and dry when retracted. If it is retracted while it is wet, it should be extended as soon as possible in order to allow it to dry.
- Check regularly to ensure that the wall brackets are securely fastened.
- Inspect the screws and nuts twice per year. Tighten them if they are loose.
- Do not use the awning if it is damaged or if it is not properly fastened. Contact an authorised technician for repairs.
- Under normal circumstances it is not necessary to lubricate the moving parts of the awning.

If lubrication is necessary, petroleum based lubricants may not be used.

- When lubricating, use a spray nozzle with tube. Thoroughly lubricate the area between the end of the supporting bar and the bracket. Avoid spraying the awning canopy.

CLEANING

- Dust and dirt accumulate on the frame over time. Therefore, it is important to clean the awning regularly to maintain an attractive appearance.
- A gentle spray cleaner or a mixture of water and cleanser can be used on the frame and then wiped clean.
- Carefully clean the canopy with a mild cleanser diluted with cold or lukewarm water. Do not use any alkaline or acidic cleansers. Only use natural soap. Let the canopy hang outdoors to dry completely. Do not use a hair dryer or another type of heated device for drying.
- Do not use high pressure washer for cleaning as this will damage the canopy's impregnation.

STORAGE

- Make sure that the canopy is dry before the awning is put in storage.
- If the awning will not be used for an extended time, we recommend removing it from the brackets and storing it in a suitable location. NOTE! At least two adults are required for removal of the awning.
- Fold the awning in completely.
- Fasten the arms of the awning so that they do not extend. The awning can be damaged if this happens. Use the safety belts which were used to tie the arms down on delivery.
- Store the awning in a dry and safe place where it is not accessible to children.

RIGHT OF COMPLAINT

By law the product must be returned to the place of purchase along with the original receipt in the event of a complaint. The user is liable for any damage to the product that is caused by not using the product for its intended purpose or by not following this user manual correctly. The right of complaint will not apply in these instances.



INFORMATION ABOUT HAZARDOUS WASTE

Used products should be handled separately from household waste. They should be taken for recycling in accordance with local rules for waste management.