
COPENHAGEN NORDIC

INSTALLATION INSTRUCTIONS


Fitting instructions are intended to ease fitting. They are not subject to contract.

Since the type of wall determines the fittings necessary for each unit, bolts and screws have not been supplied but left to the responsibility of the installer.

All electrical connections must be made in accordance with the latest IEE regulations (BSEN) by a qualified person.



Bluetooth® wireless technology enabled device operation.




When the mirror is turned off the connect on to the Bluetooth® will be lost. When the mirror is turned on again it will automatically reconnect to the last connected device.

Refer to your device manual for operating controls.

Music will stop playing when a phone call comes into the Bluetooth® device and will automatically reconnect when finished.

Trouble Shooting Guide

symptoms	possible problem	solution
Device not paired	Bluetooth [®] not activated	Check Bluetooth [®] is activated on compatible device & mirror is turned on
Device not connecting	Only one device can be connected to the mirror at any one time	Disconnect all devices and reconnect only one device
No volume	Volume is controlled from device	Increase volume on device
No connection	Out of range	Range is within 8 metres, move device closer to mirror



Enjoy, kind regards.

Copenhagen Nordic Phone +45 3696 0747